

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.

Power Supplies, Information Technology Equipment Including Electrical Business Equipment

COMPANY

MEAN WELL ENTERPRISES CO LTD

No 28 Wuquan 3rd Rd
Wugu District
New Taipei City, 24891 Taiwan

E183223

Model(s): GS160A12, GS160A15, GS160A20, GS160A24, GS160A48, HRPX-450-12 (X=G or blank), HRPX-450-15 (X=G or blank), HRPX-450-24 (X=G or blank), HRPX-450-3.3 (X=G or blank), HRPX-450-36 (X=G or blank), HRPX-450-48 (X=G or blank), HRPX-450-5 (X=G or blank), HRPX-450-7.5 (X=G or blank)

AC Adapters, Model(s): GE40Iyy (!) (#) - (yyy can be 050, 070, 090, 120, 150, 180, 240, 300, 360 or 480, z can be A-Z or 0-9) (!) - (yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36 or 48)

AC/DC Switching adapters, Model(s): GS12Uy!

AC/DC Switching Adaptor, Model(s): GC330AX (X = 36 or 48), GS220A48-AG1, GS220AX (X = 12, 15, 20, 24 or 48), GS280A24-TDSI, GS280AX (X = 12, 15, 20, 24 or 48), GST280A24-TDSI, GST280AX (X = 12, 15, 20, 24, 36 or 48)

AC/DC Switching Adaptor, Model(s): SGA12xyzzzz, x = U, I y = 05, 07, 09, 12, 15, 18, 24, 28 or 48 z=0 to 9, A to Z, hyphen or blank

AC/DC Switching Adaptor, Model(s): SGA12xyzzzz-USB x = U, I y = 05, 07, 09, 12, 15, 18, 24, 28 or 48 z=0 to 9, A to Z, hyphen or blank

AC/DC Switching adapters, Model(s): GC120A48, GS18A03, GS18A05, GS18A07, GS18A09, GS18A12, GS18A15, GS18A18, GS18A24, GS18A28, GS18A48, GS25A03, GS25A05, GS25A07, GS25A09, GS25A12, GS25A15, GS25A18, GS25A24, GS25A28, GS25A48, GSM40A48-CIS, GST18A05, GST18A07, GST18A09, GST18A12, GST18A15, GST18A18, GST18A24, GST18A28, GST18A48, GST25A05, GST25A07, GST25A09, GST25A12, GST25A15, GST25A18, GST25A24, GST25A28, GST25A48, GST36X05, GST36X09, GST36X12, GST36X24, GST36X48

AC/DC Switching adapters, Model(s): GS120AX, GST120AX (x=12, 15, 20, 24, 48)

AC/DC Switching adapters, Model(s): GS160AX (X=12,15,20,24,48), GS160A24-R7BTE

AC/DC Switching adapters, Model(s): GS25B17, where w = 18 or 25, x = B or U, and y can be 03, 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GST18XY, where X = B or U and Y = 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GST25XY, where X = B or U and Y = 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GSwx, where w = 18 or 25, x = B or U, and y can be 03, 05, 07, 09, 12, 15, 18, 24, 28 or 48

Adapter, Model(s): GS05U-USB

Direct Plug-in Adapter, Model(s): SGA60Uy-zzz y can be 05, 07, 09, 12, 15, 18, 24,28,48 -zzz can be 0- 9 ,A-Z , - or blank for marketing purpose.

Direct plug-in switching power adapters, Model(s): ES25Uyy-zzz, where yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Power Adapter, Model(s): GE12I03-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I05-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I07-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I09-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I12-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I15-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I18-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12I24-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank

Power Adapter, Model(s): GE12Iyy ("xx"= 05, 07, 09, 12, 15, 18 or 24, "z"= A, B, C, U, E, I, SU or SE)("yy" =05,07,09,12,15,18 or 24)

Power Adapter, Model(s): GE18I03-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I05-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I07-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I09-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I12-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I15-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I18-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I24-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I30-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I36-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I48-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I03-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I05-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I07-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I09-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I12-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I15-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I18-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I24-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I30-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I36-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I48-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I12-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I15-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I18-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I24-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I30-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I36-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I48-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GEzzIvv ("uu" = 030E, 024 or 018, "vv" = 03, 05, 07, 09, 12, 15, 18, 24, 30, 36 or 48 for "uu"=024 or 018, "vv" = 12, 15, 18, 24, 30, 36 or 48 for "uu" = 030E "w" = U, I or 8) ("zz" = 18, 24 or 30 "zz" = 18, 24, "vv"=05,07,09,12,15,18 ,24,48 "zz" = 30 "vv"=12,15,18,24)

Power adapters, Model(s): P25x-zzz, P50x-y-zzz

Power adapters, Model(s): PSU66x-y-zzz (a) (a) - x = A,B,C,D y = 0-8 z = 0-9, A-Z or blank

Power supplies, Model(s): ES-3 (Class I), ES-3A (Class II), IA-60a, LPP-150-12M, Pw-120N-yCz*, Pw-120P-yCz*, SP-125CL

Power supplies, Model(s): ES18XYY-ZZZ Where X can be A or C, YY can be 03, 05, 07, 09, 12, 15, 18, 24, 30 or 48, ZZZ denotes the output voltage, can be 030 - 500

Power supplies, Model(s): ES18XYY-ZZZ Where X can be B or U, YY can be 03, 05, 07, 09, 12, 15, 18, 24, 30 or 48, ZZZ can be 030-500 (indicate output voltage).

POWERDSINE 8001, Model(s): PD-8001/AC-xxxxxxxxxx, PD-8001-xxxxxxxxxx, POWERDSINE 8001

Switching adapters, Model(s): GST160A12, GST160A15, GST160A20, GST160A24, GST160A24-SP, GST160A36, GST160A48, GST40Ax, GST60Ax (b)

Switching mode power supplies, Model(s): ENC-120-x (d), ENC-180-12, ENC-180-24, ENC-180-48, ENC-240-12, ENC-240-24, ENC-240-48, ENP-120-x (d), ENP-180-12, ENP-180-24, ENP-180-48, ENP-240-12, ENP-240-24, ENP-240-48, GC330A36, GC330A48, GS220A12, GS220A15, GS220A20, GS220A24, GS220A48, GS280A12, GS280A15, GS280A20, GS280A24, GS280A48, GST280A12, GST280A15, GST280A20, GST280A24, GST280A36, GST280A48

Switching power adapters, Model(s): AS-120PX Series, GS40A05, GS40A07, GS40A09, GS40A12, GS40A15, GS40A18, GS40A24, GS40A48, GS60A05, GS60A07, GS60A09, GS60A12, GS60A15, GS60A18, GS60A24, GS60A48, GS60A48-CIS, GS60A56-NV1

Switching power adapters, Model(s): ES25Byy-zzz, where yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Switching power adapters, Model(s): ES25xyy-zzz, where x can be A or C, yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Switching power adapters, Model(s): GC30x-y, (where x = B or U, y = 0, 1, 2, 4, 5, 6 or 11)

Switching power adapters, Model(s): GS90A12, GST90A12, GS90A15, GST90A15, GS90A19, GST90A19, GS90A24, GST90A24, GS90A48, GST90A48, GS90A56-NV1, GS90A24-R7BVS

Switching power supplies, Model(s): GST220A12, GST220A15, GST220A20, GST220A24, GST220A36, GST220A48, GST220A48-AG1

Switching power supplies, Model(s): GS06U-0-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-1-1-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-1-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-2-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-3-zzz where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-4-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-5-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-6-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-7-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-8-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS15z-0-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-1-1-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-1-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-2-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-3-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-4-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-5-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-6-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-7-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-8-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching Power Supply, Model(s): ENC-360-x (@), ENP-360-x (@)

Switching Power Supply, Model(s): GP25x-yzzzzzv Where x can be A, C or D y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D, 58F z can be 0 to 9, A to Z or dash or blank v can be U1 or Blank

Switching Power Supply, Model(s): GP50x-yzzzzzz x can be A or C ,y can be 13A, 14A, 13, 13D, 14, 14E, 16, 16-1, 36, 58F, z can be 0 to 9, A to Z or dash or blank

Switching Power Supply, Model(s): SGA18xy-zzz x can be B, U or I y can be 05, 07, 09, 12, 15, 18, 24 ,28 ,48 -zzz can be 0- 9 ,A-Z , or blank for marketing purpose B = IEC-320 C8 AC Inlet U = Wall mount American plug I = American interchangeable plug

Switching Power Supply, Model(s): SGA25xyzzzzz x= B, D, U, I y=05,07,09,12,15,18,24,28,48 z= 0 - 9, A - Z or "-"or Blank

Switching Power Supply, Model(s): SGA40xy-zzz x can be U or I y can be 05, 07, 09, 12, 15, 18, 24, 28 ,48 -zzz can be 0- 9 ,A-Z , or blank for marketing purpose U = Wall mount American plug I = American interchangeable plug

Last Updated on 2023-06-12

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2024 UL LLC."

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.

Power Supplies, Information Technology Equipment Including Electrical Business Equipment Certified for Canada

COMPANY

MEAN WELL ENTERPRISES CO LTD

No 28 Wuquan 3rd Rd
Wugu District
New Taipei City, 24891 Taiwan

E183223

Model(s): GS160A12, GS160A15, GS160A20, GS160A24, GS160A48, HRPX-450-12 (X=G or blank), HRPX-450-15 (X=G or blank), HRPX-450-24 (X=G or blank), HRPX-450-3.3 (X=G or blank), HRPX-450-36 (X=G or blank), HRPX-450-48 (X=G or blank), HRPX-450-5 (X=G or blank), HRPX-450-7.5 (X=G or blank)

AC Adapters, Model(s): GE40Iyy (!) (#) - (yyy can be 050, 070, 090, 120, 150, 180, 240, 300, 360 or 480, z can be A-Z or 0-9) (!) - (yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36 or 48)

AC/DC Switching adapters, Model(s): GS12Uy!

AC/DC Switching Adaptor, Model(s): GC330AX (X = 36 or 48), GS220A48-AG1, GS220AX (X = 12, 15, 20, 24 or 48), GS280A24-TDSI, GS280AX (X = 12, 15, 20, 24 or 48), GST280A24-TDSI, GST280AX (X = 12, 15, 20, 24, 36 or 48)

AC/DC Switching Adaptor, Model(s): SGA12xyzzzz x = U, I y = 05, 07, 09, 12, 15, 18, 24, 28 or 48 z=0 to 9, A to Z, hyphen or blank

AC/DC Switching Adaptor, Model(s): SGA12xyzzzz-USB x = U, I y = 05, 07, 09, 12, 15, 18, 24, 28 or 48 z=0 to 9, A to Z, hyphen or blank

AC/DC Switching adapters, Model(s): GC120A48, GS18A03, GS18A05, GS18A07, GS18A09, GS18A12, GS18A15, GS18A18, GS18A24, GS18A28, GS18A48, GS25A03, GS25A05, GS25A07, GS25A09, GS25A12, GS25A15, GS25A18, GS25A24, GS25A28, GS25A48, GSM40A48-CIS, GST18A05, GST18A07, GST18A09, GST18A12, GST18A15, GST18A18, GST18A24, GST18A28, GST18A48, GST25A05, GST25A07, GST25A09, GST25A12, GST25A15, GST25A18, GST25A24, GST25A28, GST25A48, GST36X05, GST36X09, GST36X12, GST36X24, GST36X48

AC/DC Switching adapters, Model(s): GS120AX, GST120AX (x=12, 15, 20, 24, 48)

AC/DC Switching adapters, Model(s): GS160AX (X=12,15,20,24,48), GS160A24-R7BTE

AC/DC Switching adapters, Model(s): GS25B17, where w = 18 or 25, x = B or U, and y can be 03, 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GST18XY, where X = B or U and Y = 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GST25XY, where X = B or U and Y = 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC Switching adapters, Model(s): GSwx, where w = 18 or 25, x = B or U, and y can be 03, 05, 07, 09, 12, 15, 18, 24, 28 or 48

Adapter, Model(s): GS05U-USB

Direct Plug-in Adapter, Model(s): SGA60Uy-zzz y can be 05, 07, 09, 12, 15, 18, 24,28,48 -zzz can be 0- 9 ,A-Z , - or blank for marketing purpose.

Direct plug-in switching power adapters, Model(s): ES25Uyy-zzz, where yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Power Adapter, Model(s): GE12I03-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I05-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I07-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I09-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I12-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I15-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I18-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12I24-zzz(\$)(@) - "z"=8, U, SU, NU or I. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE12Iyy ("xx"= 05, 07, 09, 12, 15, 18 or 24, "z"= A, B, C, U, E, I, SU or SE)("yy" =05,07,09,12,15,18 or 24)

Power Adapter, Model(s): GE18I03-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I05-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I07-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I09-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I12-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I15-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I18-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I24-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I30-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I36-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE18I48-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I03-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I05-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I07-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I09-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I12-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I15-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I18-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I24-zzz(\$)(^) - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I30-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I36-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE24I48-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I12-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I15-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I18-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I24-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I30-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I36-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GE30I48-zzz(\$)^ - "w" = U, I or 8. (\$) - zzz=0~9, A~Z or blank.

Power Adapter, Model(s): GEzzIvv ("uu" = 030E, 024 or 018, "vv" = 03, 05, 07, 09, 12, 15, 18, 24, 30, 36 or 48 for "uu"=024 or 018, "vv" = 12, 15, 18, 24, 30, 36 or 48 for "uu" = 030E "w" = U, I or 8) ("zz" = 18,24 or 30 "zz" = 18, 24, "vv"=05,07,09,12,15,18 ,24,48 "zz" = 30 "vv"=12,15,18,24)

Power adapters, Model(s): P25x-zzz

Power adapters, Model(s): P50x-y-zzz x = A, B, C, D y = 12, 13, 14, 16, 16-1, 36, 13D, 14E, 12C, 13A, 14A, 13D-1, 13G, 631 z = 0-9, A-Z or blank

Power adapters, Model(s): PSU66x-y-zzz (a) (a) - x = A,B,C,D y = 0-8 z = 0-9, A-Z or blank

Power supplies, Model(s): ES-3 (Class I), ES-3A (Class II), IA-60a, LPP-150-12M, Pw-120N-yCz*, Pw-120P-yCz*, SP-125CL

Power supplies, Model(s): ES18XYY-ZZZ Where X can be A or C, YY can be 03, 05, 07, 09, 12, 15, 18, 24, 30 or 48, ZZZ denotes the output voltage, can be 030 - 500

Power supplies, Model(s): ES18XYY-ZZZ Where X can be B or U, YY can be 03, 05, 07, 09, 12, 15, 18, 24, 30 or 48, ZZZ can be 030-500 (indicate output voltage).

POWERDSINE 8001, Model(s): PD-8001/AC-xxxxxxxxxx, PD-8001-xxxxxxxxxx, POWERDSINE 8001

Switching adapters, Model(s): GST160A12, GST160A15, GST160A20, GST160A24, GST160A24-SP, GST160A36, GST160A48, GST40Ax, GST60Ax (b)

Switching mode power supplies, Model(s): ENC-120-x (d), ENC-180-12, ENC-180-24, ENC-180-48, ENC-240-12, ENC-240-24, ENC-240-48, ENP-120-x (d), ENP-180-12, ENP-180-24, ENP-180-48, ENP-240-12, ENP-240-24, ENP-240-48, GC330A36, GC330A48, GS220A12, GS220A15, GS220A20, GS220A24, GS220A48, GS280A12, GS280A15, GS280A20, GS280A24, GS280A48, GST280A12, GST280A15, GST280A20, GST280A24, GST280A36, GST280A48

Switching power adapters, Model(s): AS-120PX Series, GS40A05, GS40A07, GS40A09, GS40A12, GS40A15, GS40A18, GS40A24, GS40A48, GS60A05, GS60A07, GS60A09, GS60A12, GS60A15, GS60A18, GS60A24, GS60A48, GS60A48-CIS, GS60A56-NV1

Switching power adapters, Model(s): ES25Byy-zzz, where yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Switching power adapters, Model(s): ES25xyy-zzz, where x can be A or C, yy can be 05, 07, 09, 12, 15, 18, 24, 30, 36, or 48, zzz can be 0-9.

Switching power adapters, Model(s): GC30x-y, (where x = B or U, y = 0, 1, 2, 4, 5, 6 or 11)

Switching power adapters, Model(s): GS90A12, GST90A12, GS90A15, GST90A15, GS90A19, GST90A19, GS90A24, GST90A24, GS90A48, GST90A48, GS90A56-NV1, GS90A24-R7BVS

Switching power supplies, Model(s): GST220A12, GST220A15, GST220A20, GST220A24, GST220A36, GST220A48, GST220A48-AG1

Switching power supplies, Model(s): GS06U-0-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-1-1-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-1-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-2-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-3-zzz where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-4-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-5-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-6-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-7-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS06U-8-ZZZ where z or Z can be any alphanumeric character or blank

Switching power supplies, Model(s): GS15z-0-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-1-1-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-1-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-2-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-3-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-4-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-5-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-6-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-7-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching power supplies, Model(s): GS15z-8-yyy where z can be A, B, C, D or U x can be 0, 1, 1-1, 2, 3, 4, 5, 6, 7 or 8 to denote different o/p y can be 0-9, A-Z or blank.(e) - where z can be A, B, C, D or U

Switching Power Supply, Model(s): ENC-360-x (@), ENP-360-x (@)

Switching Power Supply, Model(s): GP25x-yzzzzzv Where x can be A, C or D y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D, 58F z can be 0 to 9, A to Z or dash or blank v can be U1 or Blank

Switching Power Supply, Model(s): GP50x-yzzzzzz x can be A or C ,y can be 13A, 14A, 13, 13D, 14, 14E, 16, 16-1, 36, 58F, z can be 0 to 9, A to Z or dash or blank

Switching Power Supply, Model(s): SGA18xy-zzz x can be B, U or I y can be 05, 07, 09, 12, 15, 18, 24 ,28 ,48 -zzz can be 0- 9 ,A-Z , or blank for marketing purpose B = IEC-320 C8 AC Inlet U = Wall mount American plug I = American interchangeable plug

Switching Power Supply, Model(s): SGA25xyzzzzz x= B, D, U, I y=05,07,09,12,15,18,24,28,48 z= 0 - 9, A - Z or "-"or Blank

Switching Power Supply, Model(s): SGA40xy-zzz x can be U or I y can be 05, 07, 09, 12, 15, 18, 24, 28 ,48 -zzz can be 0- 9 ,A-Z , or blank for marketing purpose U = Wall mount American plug I = American interchangeable plug

Last Updated on 2023-06-12

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2024 UL LLC."

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.

Power Supplies for Use with Audio/Video, Information and Communication Technology Equipment

COMPANY

MEAN WELL ENTERPRISES CO LTD

No 28 Wuquan 3rd Rd
Wugu District
New Taipei City, 24891 Taiwan

E183223

Model(s): GC30x-y x= B denote unit use inlet x=U denote unit used non-detachable power supply cord of US plug y can be 0, 1, 2, 4, 5, 6 or 11 for the different output rating

Model(s): GST18xy (x can be B or U), (y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48)

Model(s): GST25xy (x can be B or U), (y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48)

Model(s): GST36xy (x can be B or U), (y can be 05, 09, 12, 24 or 48)

Model(s): NGE30xyzzzz (x= I or U, y=05, 09, 12, 15, 18, 24, 48 which denoted for output voltage, zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

100W GaN Fast Charger, Model(s): NGE100xyyyy x=Blank, U, yyy=maybe blank, -, 0~9, A~Z or a~z for market purpose

AC/DC Switching Adapter, Model(s): NGE12xyzzz x=U,I,U type which is foldable but non-detachable, I type is non-foldable metal pins used with detachable US plug. y=05,09,12,15,18,24,which denoted for output voltage. zzzz=maybe Blank, -, 0~9, A~Z or a~z for market purpose.

AC/DC Switching Adapter, Model(s): NGE18xyzzz x=U,I,U type which is foldable but non-detachable, I type is non-foldable metal pins used with detachable US plug. y=05,09,12,15,18,24,which denoted for output voltage. zzzz=maybe Blank, -, 0~9, A~Z or a~z for market purpose.

AC/DC Switching Adapter, Model(s): NGE45xyzzzz (x= I, U. y= 05, 09, 12, 15, 18, 24, 48 which denoted for output voltage. zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

AC/DC Switching Adapter, Model(s): NGE65xyzzzz (x= I, U. y= 05, 09, 12, 15, 18, 24, 48 which denoted for output voltage. zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

AC/DC Switching Adapter, Model(s): NGE90xyzzzz (x=U, I, y=12, 15, 18, 24, 48, 55, zzzz= maybe Blank, -,0~9, A~Z or a~z for market purpose)

AC/DC Switching Adaptor, Model(s): GST360Ax where x can be 12, 15, 24, 36, 48 or 55 which denoted for output voltage

AC/DC Switching Adaptor, Model(s): GST360Bx where x can be 12, 15, 24, 36, 48 or 55 which denoted for output voltage

AC/DC SWITCHING ADAPTOR, Model(s): GC330Ay y= 36, 48, GST160A12, GST160A15, GST160A20, GST160A24, GST160A36, GST160A48, GST220A48-AG1, GST90Ax (x can be 12, 15, 19, 24 or 48)

AC/DC SWITCHING ADAPTOR, Model(s): GST18Ay y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST220Ax x can be 12, 15, 20, 24, 36 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST25Ay y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST280Ax x= 12, 15, 20, 24, 24-TDSI, 36, 48

AC/DC Switching adaptors, Model(s): GS120A12, GST120A12, GST120A15, GST120A20, GST120A24, GST120A48, GST40A05, GST40A07, GST40A09, GST40A12, GST40A15, GST40A18, GST40A24, GST40A48, GST60A05, GST60A07, GST60A09, GST60A12, GST60A15, GST60A18, GST60A24, GST60A48

Switch Power Supply, Model(s): OWA-200U-12, OWA-200U-20, OWA-200U-24, OWA-200U-36, OWA-200U-42, OWA-200U-48, OWA-200U-54

Switching Power Supply, Model(s): ENC-120-x x can be 12, 24 or 48, ENC-180-x where x can be 12, 24 or 48, ENC-240-x where x can be 12, 24 or 48, ENC-360-x (x can be 12, 24 or 48), ENP-120-x x can be 12, 24 or 48, ENP-180-x where x can be 12, 24 or 48, ENP-240-12BC, ENP-240-x where x can be 12, 24 or 48, ENP-360-x (x can be 12, 24 or 48)

Switching Power Supply, Model(s): GP25x-yzzzzzv where x can be B or D. y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D or 58F. z can be 0 to 9, A to Z, dash or blank. v can be U or blank.

Switching Power Supply, Model(s): GP25x-yzzzzzv where x can be A, C or D. y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D or 58F. z can be 0 to 9, A to Z, dash or blank. v can be U1 or blank.

Switching Power Supply, Model(s): GP50abzzzzz - Where a = A or C, b = 13, 13A, 13D, 14, 14A, 14E, 16, 16-1, 36, 58F or 73I, z = 0 to 9, A to Z, dash or blank.

Switching Power Supply, Model(s): NPB-x-yz x=120 or 360, y=12 or 24, z=AD1 or XLR

SWITCHING POWER SUPPLY, Model(s): SGAS06xbzzzzz

SWITCHING POWER SUPPLY, Model(s): GS05xzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): GS06x-yzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): GS15x-yzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): GS15x-yzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA12xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA12xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA18xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA18xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA25xbzzzzz where x can be U, UI, I or B. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGA25xbzzzzz where x can be A or C. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGA40abzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

SWITCHING POWER SUPPLY, Model(s): SGA60wbzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

SWITCHING POWER SUPPLY, Model(s): SGAS06Ibzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): SGAS12xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1. b =03,05,07,09,12,15,18,24,28,48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS12xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1, b =03,05,07,09,12,15,18,24,28,48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS15xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1. b =03,05,07,09,12,15,18,24,28,48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS15xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1, b =03,05,07,09,12,15,18,24,28,48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS18xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1. b =03,05,07,09,12,15,18,24,28,48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS18xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11or 1-1, b =03,05,07,09,12,15,18,24,28,48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS25xbzzzzz where x can be U, UI, I or B. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGAS25xbzzzzz where x can be A or C. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGAS60abzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

Last Updated on 2024-03-01

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2024 UL LLC."

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.

Power Supplies for Use with Audio/Video, Information and Communication Technology Equipment Certified for Canada

COMPANY

MEAN WELL ENTERPRISES CO LTD

No 28 Wuquan 3rd Rd
Wugu District
New Taipei City, 24891 Taiwan

E183223

Model(s): GC30x-y x= B denote unit use inlet x=U denote unit used non-detachable power supply cord of US plug y can be 0, 1, 2, 4, 5, 6 or 11 for the different output rating

Model(s): GST18xy (x can be B or U), (y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48)

Model(s): GST25xy (x can be B or U), (y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48)

Model(s): GST36xy (x can be B or U), (y can be 05, 09, 12, 24 or 48)

Model(s): NGE30xyzzzz (x= I or U, y=05, 09, 12, 15, 18, 24, 48 which denoted for output voltage, zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

100W GaN Fast Charger, Model(s): NGE100xyyyy x=Blank, U, yyyy=maybe blank, -, 0~9, A~Z or a~z for market purpose

AC/DC Switching Adapter, Model(s): NGE12xyzzz x=U,I,U type which is foldable but non-detachable, I type is non-foldable metal pins used with detachable US plug. y=05,09,12,15,18,24,which denoted for output voltage. zzzz=maybe Blank, -, 0~9, A~Z or a~z for market purpose.

AC/DC Switching Adapter, Model(s): NGE18xyzzz x=U,I,U type which is foldable but non-detachable, I type is non-foldable metal pins used with detachable US plug. y=05,09,12,15,18,24,which denoted for output voltage. zzzz=maybe Blank, -, 0~9, A~Z or a~z for market purpose.

AC/DC Switching Adapter, Model(s): NGE45xyzzzz (x= I, U. y= 05, 09, 12, 15, 18, 24, 48 which denoted for output voltage. zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

AC/DC Switching Adapter, Model(s): NGE65xyzzzz (x= I, U. y= 05, 09, 12, 15, 18, 24, 48 which denoted for output voltage. zzzz= maybe Blank, -, 0~9, A~Z or a~z for market purpose)

AC/DC Switching Adapter, Model(s): NGE90xyzzzz (x=U, I, y=12, 15, 18, 24, 48, 55, zzzz= maybe Blank, -,0~9, A~Z or a~z for market purpose)

AC/DC Switching Adaptor, Model(s): GST360Ax where x can be 12, 15, 24, 36, 48 or 55 which denoted for output voltage

AC/DC Switching Adaptor, Model(s): GST360Bx where x can be 12, 15, 24, 36, 48 or 55 which denoted for output voltage

AC/DC SWITCHING ADAPTOR, Model(s): GC330Ay y= 36, 48, GST160A12, GST160A15, GST160A20, GST160A24, GST160A36, GST160A48, GST220A48-AG1, GST90Ax (x can be 12, 15, 19, 24 or 48)

AC/DC SWITCHING ADAPTOR, Model(s): GST18Ay y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST220Ax x can be 12, 15, 20, 24, 36 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST25Ay y can be 05, 07, 09, 12, 15, 18, 24, 28 or 48

AC/DC SWITCHING ADAPTOR, Model(s): GST280Ax x= 12, 15, 20, 24, 24-TDSI, 36, 48

AC/DC Switching adaptors, Model(s): GS120A12, GST120A12, GST120A15, GST120A20, GST120A24, GST120A48, GST40A05, GST40A07, GST40A09, GST40A12, GST40A15, GST40A18, GST40A24, GST40A48, GST60A05, GST60A07, GST60A09, GST60A12, GST60A15, GST60A18, GST60A24, GST60A48

Switch Power Supply, Model(s): OWA-200U-12, OWA-200U-20, OWA-200U-24, OWA-200U-36, OWA-200U-42, OWA-200U-48, OWA-200U-54

Switching Power Supply, Model(s): ENC-120-x x can be 12, 24 or 48, ENC-180-x where x can be 12, 24 or 48, ENC-240-x where x can be 12, 24 or 48, ENC-360-x (x can be 12, 24 or 48), ENP-120-x x can be 12, 24 or 48, ENP-180-x where x can be 12, 24 or 48, ENP-240-12BC, ENP-240-x where x can be 12, 24 or 48, ENP-360-x (x can be 12, 24 or 48), PPS-125-12, PPS-125-13.5, PPS-125-15, PPS-125-24, PPS-125-27, PPS-125-3.3, PPS-125-48, PPS-125-5, PPT-125A, PPT-125B, PPT-125C, PPT-125D

Switching Power Supply, Model(s): GP25x-yzzzzzv where x can be B or D. y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D or 58F. z can be 0 to 9, A to Z, dash or blank. v can be U or blank

Switching Power Supply, Model(s): GP25x-yzzzzzv where x can be A, C or D. y can be 13, 13A, 13D, 14, 14A, 14E, 16, 3D or 58F. z can be 0 to 9, A to Z, dash or blank. v can be U1 or blank.

Switching Power Supply, Model(s): GP50abzzzzzz - Where a = A or C, b = 13, 13A, 13D, 14, 14A, 14E, 16, 16-1, 36, 58F or 73I, z = 0 to 9, A to Z, dash or blank.

Switching Power Supply, Model(s): NPB-x-yz x=120 or 360, y=12 or 24, z=AD1 or XLR

SWITCHING POWER SUPPLY, Model(s): GS05xzzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): GS06x-yzzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): GS15x-yzzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): GS15x-yzzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA12xbzzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA12xbzzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA18xbzzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA18xbzzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGA25xbzzzzzz where x can be U, UI, I or B. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGA25xbzzzzzz where x can be A or C. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGA40abzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

SWITCHING POWER SUPPLY, Model(s): SGA60wbzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

SWITCHING POWER SUPPLY, Model(s): SGAS06Ibzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): SGAS06xbzzzzz - "x" = U or B: "y" = 0, 1, 2, 3, 4, 5, 6, 7, 8 or 1-1: "b" = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48: "z" can be 0 to 9, A to Z, hyphen or blank for marketing purpose and no impact safety related critical components and constructions for full investigation.

SWITCHING POWER SUPPLY, Model(s): SGAS12xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS12xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS15xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS15xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS18xbzzzzz (!) (!) refers to where x = A or C. y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1. b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS18xbzzzzz (\$) (\$) refers to where x = U, I and B, y = 0, 1, 2, 3, 4, 5, 6, 7, 8, 11 or 1-1, b = 03, 05, 07, 09, 12, 15, 18, 24, 28, 48, z = 0 to 9, A to Z. (when z be blank, - can be optional.)

SWITCHING POWER SUPPLY, Model(s): SGAS25xbzzzzz where x can be U, UI, I or B. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGAS25xbzzzzz where x can be A or C. y can be 0, 1, 2, 3, 4, 5, 6, 7, 8, or 1-1. b can be 03, 05, 07, 09, 12, 15, 18, 24, 28, 48. z can be 0 to 9, A to Z, hyphen or blank.

SWITCHING POWER SUPPLY, Model(s): SGAS60abzzzzz (@) (@) refers to where w = U: a = U, I: b = 05, 07, 09, 12, 15, 18, 24, 28, 48: z = 0 to 9, A to Z, hyphen or blank

Last Updated on 2024-03-01

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2024 UL LLC."